



Air Blasters Tek Six Reload Slider Replacement

This guide will show you how to replace your reload slider for the Air Blasters Tek Six

Written By: hani



INTRODUCTION

The reload slider is the mechanism that gets the blaster ready to fire the darts.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Remove screws of the grey slider



- Using a screwdriver, remove the two 11.6 mm phillips 00 screws holding the grey slider together.

Step 2 — Remove the slider



- Remove grey slider from the main body of the blaster.

To reassemble your device, follow these instructions in reverse order.

